

**R&R RR-P-569
CONTROLLER FOR 2 BLDC-MOTORS
Technical Data Sheet**

R&R GmbH
Doc. No. DNR22854
REV 01, dated 4-october-2016

TABLE OF CONTENTS

| | |
|---|----|
| LIST OF EFFECTIVE PAGES | 2 |
| RECORD OF REVISIONS | 3 |
| FIGURES | 4 |
| TABLES | 4 |
| DESCRIPTION: RR-P-569 CONTROLLER FOR 2 BLDC-MOTORS | 5 |
| 1. GENERAL | 5 |
| 2. INTERFACES | 6 |
| 2.1 POWER SUPPLY | 7 |
| 2.2 MOTOR INTERFACES | 8 |
| 2.3 DIGITAL INPUTS AND OUTPUTS | 11 |
| 2.4 SERIAL INTERFACE 1 (Isolated RS422 bus interface) | 12 |
| 2.5 SERIAL INTERFACE 2 (RS232C SERVICE INTERFACE) | 13 |
| 2.6 USB SERVICE INTERFACE | 14 |
| 2.7 ANALOGUE INPUTS | 15 |
| 3. DRAWINGS | 16 |
| 4. RR-P-569 SETUP | 18 |
| 5. RR-P-569 FIRMWARE UPDATE | 21 |

FIGURES

| | |
|---|----|
| FIGURE 1: RR-P-569 CONTROLLER FOR 2 BLDC-MOTORS | 5 |
| FIGURE 2: RR-P-569 CONNECTOR LAYOUT | 6 |
| FIGURE 3: RR-P-569 TOP VIEW | 16 |
| FIGURE 4: RR-P-569 SIDE VIEW | 16 |
| FIGURE 5: RR-P-569 SIDE VIEW | 17 |
| FIGURE 6: SERIAL PORT SETUP | 18 |
| FIGURE 7: RR-P-569 MAIN MENU | 19 |
| FIGURE 8: MENU RR-P-569 MOTOR 1 SETUP | 20 |
| FIGURE 9: RR-P-575 PROGRAMMING ADAPTER | 21 |

TABLES

| | |
|---|----|
| TABLE 1: TECHNICAL PRINCIPLES | 5 |
| TABLE 2: LIST OF CONNECTORS | 6 |
| TABLE 3: PIN ASSINGMENT CLAMP P1 – POWER SUPPLY | 7 |
| TABLE 4: TECHNICAL DETAILS MOTOR INTERFACE | 8 |
| TABLE 5: PIN ASSINGMENT CONNECTOR P2 (MOTOR INTERFACE 1) | 9 |
| TABLE 6: PIN ASSINGMENT CONNECTOR P3 (MOTOR INTERFACE 2) | 10 |
| TABLE 7: TECHNICAL DETAILS DIGITAL INPUTS AND OUTPUTS | 11 |
| TABLE 8: PIN ASSINGMENT CONNECTOR P4 (DIGITAL INPUTS AND OUTPUTS) | 11 |
| TABLE 9: PIN ASSINGMENT CONNECTOR P5 (ISOLATED RS422 BUS INTERFACE) | 12 |
| TABLE 10: PIN ASSINGMENT CONNECTOR P6 (RS232C SERVICE INTERFACE) | 13 |
| TABLE 11: PIN ASSINGMENT CONNECTOR P7 (USB SERVICE INTERFACE) | 14 |
| TABLE 12: TECHNICAL DETAILS ANALOGUE INPUTS | 15 |
| TABLE 13: PIN ASSINGMENT CONNECTOR P8 (ANALOGUE INPUTS) | 15 |

DESCRIPTION: RR-P-569 CONTROLLER FOR 2 BLDC-MOTORS

1. GENERAL

The motor-controller is used to control up to 2 brushless dc motors with hall sensors. The motor controller can be used to control 2 separate axis or as electrical shaft.




FIGURE 1: RR-P-569 CONTROLLER FOR 2 BLDC-MOTORS

TABLE 1: TECHNICAL PRINCIPLES

| | |
|--------------------------|--|
| Drawing | DNR 20665 |
| Dimension | 160 x 100 mm |
| Mounting drills | 3.5 mm at 150 x 90 mm |
| Voltage | 24V-48V/DC |
| Absolute max. Current *1 | 14A |
| current | 100 mA + motor currents (both motors) + digital outputs loads |
| Motor interface | 2 x brushless DC Motor power stage with hall sensors. |
| User interfaces | 1 x RS422 1 x RS232C 1 x USB 8 x digital I/O (function defined by software) 4 x digital outputs (1,5A max.) 2 x analogue inputs (0 – 5V 10Bits) |
| Internal sensors | temperature, current (peak and average), input voltage |
| Software | TBD |

*1) Stresses beyond those listed under “absolute maximum ratings” may cause permanent damage to the device or a malfunction of the device.

2. INTERFACES




FIGURE 2: RR-P-569 CONNECTOR LAYOUT

TABLE 2: LIST OF CONNECTORS

| Connector | designation | Interface type |
|--------------------|-------------|----------------|
| Power supply | P1 | |
| Motor interface 1 | P2 | |
| Motor interface 2 | P3 | |
| Digital I/O | P4 | |
| Serial interface 1 | P5 | RS422 / RS485 |
| Serial interface 2 | P6 | RS232C |
| Serial interface 3 | P7 | USB 2.0 |
| Analogue Interface | P8 | |

2.1 POWER SUPPLY**TABLE 3: PIN ASSINGMENT CLAMP P1 – POWER SUPPLY**

| | |
|-------------------------|----------------------|
| P1: Power supply | |
| Connector type | Spring clamps |
| 1 | + 24V DC up to 48VDC |
| 2 | GND |

2.2 MOTOR INTERFACES

TABLE 4: TECHNICAL DETAILS MOTOR INTERFACE

| | |
|-----------------------------------|---|
| Number of BLDC-motor interfaces | 2 |
| power stage | 3 half bridges for 24 up to 48 volts |
| Nominal current | 7A |
| Absolute max. Current *1 | 10A |
| Over current shut down | Average current 0 – 10A (adjustable) Peek current 20A (fix) |
| Hall-sensors | 3 |
| end-switches | Contact bounce suppression by hardware for none delay Contacts NO, NC and COM. Internal pull-up resistors 5 volts operation |
| over-current shutdown direction 1 | Shutdown is hardware controlled. Controlled by Digital potentiometers with none volatile memory. Adjusted via setup (see below) |
| delay 1 | Delay 1 is hardware controlled. Digital potentiometers with none volatile memory Adjusted via setup (see below) |
| over-current shutdown direction 2 | Shutdown is hardware controlled. Controlled by digital potentiometers with none volatile memory. Adjusted via setup (see below) |
| delay 2 | Delay 2 is hardware controlled. Digital potentiometers with none volatile memory Adjusted via setup (see below) |
| Special function | Manual override Relays are used to disconnect the power stages from the motors. |

*1) Stresses beyond those listed under “absolute maximum ratings” may cause permanent damage to the device or a malfunction of the device.

TABLE 5: PIN ASSIGNMENT CONNECTOR P2 (MOTOR INTERFACE 1)

| P2 motor 1 | | | | |
|----------------|---|---------------------|------|--------------|
| Connector type | | 15 pin sub-D female | | |
| (housing) PE | 1 | O | | |
| | | | O 9 | motor line U |
| motor line V | 2 | O | | |
| | | | O 10 | motor line W |
| hall 0V | 3 | O | | |
| | | | O 11 | hall A |
| hall B | 4 | O | | |
| | | | O 12 | hall C |
| hall +5V | 5 | O | | |
| | | | O 13 | stop1 COM |
| stop1 NC | 6 | O | | |
| | | | O 13 | NO stop1 |
| stop2 COM | 7 | O | | |
| | | | O 15 | NC |
| stop 2 NO | 8 | O | | |

TABLE 6: PIN ASSIGNMENT CONNECTOR P3 (MOTOR INTERFACE 2)

| P3 motor 2 | | | | |
|-------------------|---|---------------------|------|--------------|
| Connector type | | 15 pin sub-D female | | |
| (housing) PE | 1 | O | | |
| | | | O 9 | motor line U |
| motor line V | 2 | O | | |
| | | | O 10 | motor line W |
| hall 0V | 3 | O | | |
| | | | O 11 | hall A |
| hall B | 4 | O | | |
| | | | O 12 | hall C |
| hall +5V | 5 | O | | |
| | | | O 13 | stop1 COM |
| stop1 NC | 6 | O | | |
| | | | O 13 | NO stop1 |
| stop2 COM | 7 | O | | |
| | | | O 15 | NC |
| stop 2 NO | 8 | O | | |

2.3 DIGITAL INPUTS AND OUTPUTS

Purpose: User interface

TABLE 7: TECHNICAL DETAILS DIGITAL INPUTS AND OUTPUTS

| | |
|-----------------------------|---|
| Output 0 – 3 max. current | 1,5 A high side switches short circuit proof |
| Inputs 0 – 7 / Output 4 -11 | Function defined by software |
| Input 0 - 7 | 0/24V internal pull-up resistors 4.7 k ohms |
| Output 4 – 11 | TTL-level, 5mA |

TABLE 8: PIN ASSINGMENT CONNECTOR P4 (DIGITAL INPUTS AND OUTPUTS)

| P4: digital I/O | | | | |
|-----------------|----|---------------------|----|---------------------|
| Connector type: | | WR-MM 26 pin female | | |
| | | 0 | 1 | output 3 |
| 0V (GND) | 2 | 0 | | |
| | | 0 | 3 | output 2 |
| 0V (GND) | 4 | 0 | | |
| | | 0 | 5 | output 1 |
| 0V (GND) | 6 | 0 | | |
| | | 0 | 7 | output 0 |
| 0V (GND) | 8 | 0 | | |
| | | 0 | 9 | Input 0 / output 4 |
| 0V (GND) | 10 | 0 | | |
| | | 0 | 11 | Input 1 / output 5 |
| 0V (GND) | 12 | 0 | | |
| | | 0 | 13 | Input 2 / output 6 |
| 0V (GND) | 14 | 0 | | |
| | | 0 | 15 | Input 3 / output 7 |
| 0V (GND) | 16 | 0 | | |
| | | 0 | 17 | Input 4 / output 8 |
| 0V (GND) | 18 | 0 | | |
| | | 0 | 19 | Input 5 / output 9 |
| 0V (GND) | 20 | 0 | | |
| | | 0 | 21 | Input 6 / output 10 |
| 0V (GND) | 22 | 0 | | |
| | | 0 | 23 | Input 7 / output 11 |
| 0V (GND) | 24 | 0 | | |
| | | 0 | 25 | NC |
| 0V (GND) | 26 | 0 | | |

2.4 SERIAL INTERFACE 1 (Isolated RS422 bus interface)

Used to connect several controllers and for remote control.
 Customized Software and protocol.
 Software TBD

TABLE 9: PIN ASSINGMENT CONNECTOR P5 (ISOLATED RS422 BUS INTERFACE)

| P5 isolated RS422 bus interface | | | | |
|---------------------------------|----|----------------------------|---|------------------|
| Connector type: | | 10 pin WR-MM 10-pin female | | |
| | | | 1 | B |
| R _t | 2 | ○ | | receiver pair |
| | | | 3 | A |
| (housing) PE | 4 | ○ | | |
| | | | 5 | Z |
| R _t | 6 | ○ | | transmitter pair |
| | | | 7 | Y |
| (housing) PE | 8 | ○ | | |
| | | | 9 | isolated GND |
| (housing) PE | 10 | ○ | | |

2.5 SERIAL INTERFACE 2 (RS232C SERVICE INTERFACE)

Used for service only.
 Programming, Testing, Setup.
 Connected parallel to USB interface
 Connect only J7 or J5

To access the service screen use a terminal program (VT100 mode).
 We are using Tera Term (shareware).
 Parameters: 19200, 8, N, 1 (Baud, Bits, Parity, Stopbits)
 Follow the instruction on the service screen.

TABLE 10: PIN ASSINGMENT CONNECTOR P6 (RS232C SERVICE INTERFACE)

| P6: RS232C for service only | | | | |
|------------------------------------|------|---------------------|---|--------------|
| Connector type: | | WR-MM 10-pin female | | |
| | | ○ | 1 | program mode |
| +5V | 2 ○ | ○ | 3 | RX |
| RTS | 4 ○ | ○ | 5 | TX |
| CTS | 6 ○ | ○ | 7 | reset |
| setup | 8 ○ | ○ | 9 | 0V (GND) |
| | 10 ○ | | | |

2.6 USB SERVICE INTERFACE

On board USB to RS232C Converter
Connected parallel to serial interface 2
Used for service only.
Programming, Testing, Setup.
Connect only J7 or J5

To access the service screen use a terminal program (VT100 mode).
We are using Tera Term (shareware).
Parameters: 19200, 8, N, 1 (Baud, Bits, Parity, Stop bits)
Follow the instruction on the service screen.

TABLE 11: PIN ASSINGMENT CONNECTOR P7 (USB SERVICE INTERFACE)

| P7 USB | |
|----------------|-------------|
| Connector type | JST PH 5pin |
| 1 | 5V-USB |
| 2 | D- |
| 3 | D+ |
| 4 | GND |

2.7 ANALOGUE INPUTS

TABLE 12: TECHNICAL DETAILS ANALOGUE INPUTS

| | |
|------------------------------|--|
| Analogue 1 (internal) | Temperature: -40°C up to +100°C resolution approx. 1/2 degree Celsius |
| Analogue 2 (internal) | Operation voltage 0 up to 55V resolution about 55mV |
| Analogue 3 (internal) | Average motor current 1, 0 up to 9A resolution approx. 9mA |
| Analogue 4 (internal) | Average motor current 2, 0 up to 9A resolution approx. 9mA |
| Analogue 5 (general purpose) | 0 – 5V DC, resolution 10 bits |
| Analogue 6 (general purpose) | 0 – 5V DC, resolution 10 bits |

TABLE 13: PIN ASSINGMENT CONNECTOR P8 (ANALOGUE INPUTS)

| P8 analogue inputs | |
|---------------------------|-------------|
| Connector type | JST PH 6pin |
| 1 | Analogue 5 |
| 2 | Analogue 6 |
| 3 | GND |
| 4 | GND |
| 5 | +5V |
| 6 | +5V |

3. DRAWINGS




FIGURE 3: RR-P-569 TOP VIEW




FIGURE 4: RR-P-569 SIDE VIEW




FIGURE 5: RR-P-569 SIDE VIEW

4. RR-P-569 SETUP

The ST107 (motor controller RR-P-569) does have an USB to serial converter on board.
Use a VT100 compatible terminal program (TeraTerm or comparable).

Procedure:

The Motor controller and the pc are switched off.
Connect the USB or serial cable on both sides.
Switch on the pc.

Start the terminal program.

Select the correct com port.

The TeraTerm terminal program does support only COM1, COM2, COM3, COM4!

Use the following Parameters: 19200, 8, NONE, 1, NONE




FIGURE 6: SERIAL PORT SETUP

Save the setup

Switch on the motor controller (connect the power supply to P1).

Note:


The controller RR-P-569 is streaming data on the serial port.

Windows operating system may try to install a mouse driver when streaming data is detected on a serial port! This can block the access to serial port.

Then menu may vary for different applications.

Example:

The following menu will appear:



```
Tera Term - COM1 VT
Datei Bearbeiten Einstellungen Steuerung Fenster Hilfe
RR-P-569-motor-controller v 0.0.1 build Sep 19 2016/15:01:29

inputs  outputs  motor1          motor2          ambient-parameter
=====
I0  0  Q0  0  current1  0.02 A  current2  0.02 A  supply  23.95 v
I1  0  Q1  0  relay1    1       relay2    0       temp.  +31 deg C
I2  0  Q2  0  run1      117;66H 500    0
I3  0  Q3  1  direction1 0       direction2 0
I4  0  overcurrent1 0       overcurrent2 0
I5  0  rmp1        0       rmp2        0       work    +1.0000 rpm
I6  0  end1        0       end3        1       ramp    +1.0000 rpm
I7  0  end2        0       end4        1       step    +2.0000 rpm
      position 0.0000  0.0000
      m-state  5


application# 2      speed start 500      speed run 4000      speed stop 500

=====
press M1 or M2 for Motor parameter setup
press A for set application
press I for interactive mode
```

FIGURE 7: RR-P-569 MAIN MENU

Press space to redraw.

Press M1 to modify the current max values of Motor 1.
Press M2 to modify the current max values of Motor 2.
Use the same parameters for both motors
The menu is case sensitive!
The following menu will appear:



```
Tera Term - COM1 VT
Datei Bearbeiten Einstellungen Steuerung Fenster Hilfe
R&R RR-P-569 motor 1 setup
-----
1. idle speed          5000 rpm @ 48000 mV
2. i x r compensation 1500 mOhms
3. p-factor           100 limit   100
4. i-factor           8 limit   200
5. pole pairs         7
6. current limiter @ 10000 mA
-----
7. ramp                1000 rpm / s
8. direction           0
-----
9. delay                200 ms   102 102
A. current up max      1500 mA  40 40
B. current down max    1500 mA  40 40
-----
D. load defaults
-----
0 save & exit,   ESC quit without save
```

FIGURE 8: MENU RR-P-569 MOTOR 1 SETUP

Increase the values in steps of 100mA.

Press A to change current up max.
Press B to change current down max.

Don't change other parameters.
Press "0" (Zero) to save the changes.
Use ESC to exit without saving.

5. RR-P-569 FIRMWARE UPDATE




FIGURE 9: RR-P-575 PROGRAMMING ADAPTER

Connect the Programming Adapter RR-P-575 to the service interface (connector P6).

Switch on the motor controller (connect the power supply to P1)

Use a Switch between PIN 1 and PIN 6 to select the Program mode
PIN 1 must be connected permanently to +5V DC.

Use a push button between PIN 4 and PIN 6
Push the button to perform a Reset
(The PIN 4 must be set to +5V PIN 6)

Connect the serial port to a windows PC.

Programming operation

Use the supplied flash utility.
Start the program.
Load the firmware file.

Download the control program to the processor. – Download -

Erase the flash memory.
Perform a reset.
Download the new firmware by using the FULL-OPERATION
Wait until the download is completed.

Leave the program mode.
Perform a Reset.
Release the ON-Button.
The firmware is now loaded. The machine is running normally.
Close the programming utility.
Access the service screen of the machine.
All parameters must be controlled.
If you have any doubts load the default parameters.